

Entering the user name and password when using the Web Setup function

When using "Web Setup", you need to enter a user name and a password.
The initial settings for the user name and password are as follows :

User name : admin

Password : admin

- Refer to the instruction manual for details about "Web Setup".
- You can start changing the user name and password during "Web Setup".

使用 Web Setup 功能时输入用户名和密码

使用“Web Setup”时，需要输入用户名和密码。

初始用户名和密码如下：

用户名：admin

密码：admin

- 有关“Web Setup”的详细信息，请参阅说明手册。
- 可在“Web Setup”过程中开始更改用户名和密码。

Web Setup機能使用時のユーザー名・パスワードの入力について

「Web Setup」を使用するには、ユーザー名とパスワードの入力が必要です。
ユーザー名とパスワードの初期設定は次の通りです。

User name: admin

Password: admin

- 「Web Setup」の詳細については取扱説明書をご覧ください。
- ユーザー名とパスワードは「Web Setup」の中から変更することができます。